

Installation Template For LT783 / 786 KS, KV, LS, LV

STRIKE TEMPLATE

LATCH TEMPLATE

Door face

Door edge

Door thickness

Mounting screw for Standard T strike, Extended Full Lip and T Strike

Mount. screw for LT-SE182 Full Lip Strike

1" X 5/8" deep

Strike Center

Fold on dotted line and place against the door stop. Mark the position of necessary holes for Jam bore

Door thickness

2" 1-3/4" 1-3/8"

Fold on dotted line and attach to the door at desire height. Mark the position of necessary holes for Face and Edge bores.

Backset 2-3/8" (60mm)

Backset 2-3/4" (70mm)

Edge bore
-2-3/8" drill 3-3/4" deep
-2-3/4" drill 4" deep

CAUTION!
1/2" Face bore for LS/LV, and
1-3/8" (35mm) Minimum Face bore for KS / KV.
Please refer to the trim set template or consult with trim set provider as you may need larger face bore.

5/32" deep

Mount. screw for Faceplate

1-3/8" 1-3/4" 2"

Door thickness

